Pre-Assembly

PLANNING ASSEMBLY

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

HARDWARE INCLUDED

NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6X15 Bolt	24
BB	M6 Flat Washer	92
CC	M6X25 Bolt	16
DD	M6X15 Bolt	24
EE	M6X25 Bolt	12
FF	M6X35 Stainless Steel Bolt	4
GG	M6 Stainless Steel Flat Washer	4
HH	M6X35 Bolt	16
II	Ground Stake ¢8x180	8
JJ	M6 Wrench	2

Pre-Assembly (continued)

PACKAGE CONTENTS



. A



. B



. C



. D

. E

. F



. G



. H



. I

. J



. K1



. K2



. L



. M

. N



. O

. P



. Q



. R



. S



. T

. U

. V

. W

Part	Description	Quantity
A	Post 1	1
B	Post 2	1
C	Post 3	1
D	Post 4	1
E	Top beam	2
F	Beam	1
G	Hook	2
H	Big cover	2
I	Small cover	1
J	Front panel	2
K1	Side panel 1	2
K2	Side panel 2	2
L	Bottom board	2
M	Post beam	2
N	Wine glass holder	1
O	Screen	1
P	Table top	2
Q	Big rack	1
R	Small rack	1
S	Napkin holder	1
T	Paper towel holder	1
U	Cup holder	3
V	Utensil hook	3
W	Connector	8

Assembly

1 Attaching the top beams to the posts

□ Insert the top beam (E) into post 1 (A), post 2 (B), post 3 (C), and post 4 (D), secure with flat washers (BB) and bolts (AA).

NOTE: To avoid destroying the finish, please handle it with care.



2 Attaching the front and side panels to the bottom boards

□ Tighten the front panels (J) and side panels 1 and 2 (K1 and K2 using bolts (EE) and flat washers (BB).

□ Tighten the front panel (J) and bottom board (L) using bolts (EE and flat washers (BB).



3 Connecting the frame to the posts

□ Lift the assembled frame and secure them to the posts by using bolts (HH) and flat washers (BB).



4 Attaching the table top

□ Put the table top (P) onto the top of the assembly frame. Attac with connectors (W), bolts (DD), and flat washers (BB). Connec the table top (P) and front panel (J) using connectors (W), bolts (AA), and flat washers (BB).



Assembly (continued)

5 Attaching the screen

□ Attach the screen (O) onto the middle of post 2 (B) and post 3 (C) using stainless steel bolts (FF) and stainless steel flat washers (GG).

NOTE: To avoid destroying the finish, please handle it with care.



6 Attaching the post beams

□ Attach the post beams (M) to the ends of the posts (A - D) usin bolts (DD) and flat washers (BB).

NOTE: To avoid destroying the finish, please handle it with care.



7 Attaching the wine glass holder

□ Attach the wine glass holder (N) to the top of post 1 (A) and post 4 (D) with bolts (AA) and flat washers (BB).



8 Attaching the long beam to the top beams

□ Attach the long beam (F) to the top long beams (E) using flat washers (BB) and bolts (AA).



Assembly (continued)

9 Attaching the hook

□ Screw the hook (G) on the beam (F) as shown.



10 Attaching the big cover

□ Attach the big cover (H) to the ends of the inside of the side frames using bolts (CC) and flat washers (BB



11 Securing the big cover

□ Secure the big cover (H) to the upper side of the inside of the frame assembly using bolts (BB) and flat washers (BB).



12 Securing the gazebo

□ Attach the small cover (I) to the top beams (E) using bolts (CC) and flat washer (BB). Secure the completely assembled grill gazebo into the ground using the ground stakes (II).